



B&T APC Stock Adaptor

- Must be installed by a qualified gun smith. Midwest Industries Inc. is NOT responsible for damage to firearm or person
 - Make sure your firearm is unloaded and pointed in a safe direction.
 - Remove stock bolt and QD sling plate block on your B&T APC
 - Install the MI block, and torque stock bolt to 15inch/lbs.
- Please contact us if you have any questions 262-896-6780**



B&T APC Stock Adaptor

- Must be installed by a qualified gun smith. Midwest Industries Inc. is NOT responsible for damage to firearm or person
 - Make sure your firearm is unloaded and pointed in a safe direction.
 - Remove stock bolt and QD sling plate block on your B&T APC
 - Install the MI block, and torque stock bolt to 15inch/lbs.
- Please contact us if you have any questions 262-896-6780**



B&T APC Stock Adaptor

- Must be installed by a qualified gun smith. Midwest Industries Inc. is NOT responsible for damage to firearm or person
 - Make sure your firearm is unloaded and pointed in a safe direction.
 - Remove stock bolt and QD sling plate block on your B&T APC
 - Install the MI block, and torque stock bolt to 15inch/lbs.
- Please contact us if you have any questions 262-896-6780**