



MIDWEST INDUSTRIES INC.

CZ Scorpion Pistol Handguard

Installation Instructions

We recommend these handguards be installed by a qualified gunsmith

Do not attempt to remove the six small screws that hold the handguard to the mounting block; these are permanently installed. Removing or attempting to remove any of these will void the warranty.

- 1) Make sure your CZ scorpion is unloaded and pointed in a safe direction.
- 2) Repeat Step 1
- 3) Remove the factory handguard. This will require: a 20mm wrench or use the MI Scorpion barrel nut socket; part number MI-CZSW. This may require heat being applied to the barrel nut with a pencil torch. Remove the handguard and steel sling attachment points.
- 4) Using the supplied 5/32 allen wrench loosen the mounting block bolt.
- 5) Remove the factory charging handle and slide it into the preferred side of the MI Scorpion handguard.
- 6) Slide the handguard onto the pistol and fully seat to the rear.
- 7) Tighten the mounting screw to 55 inch lbs.
- 8) Install your preferred muzzle attachment.

