



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6780

[www.midwestindustriesinc.com](http://www.midwestindustriesinc.com)

**Midwest Industries, Inc.**

**Part# MI-G2Sub-T2**

**(G2 Sub 2000 T1, T2 Optic Mount)**

**Features Include:**

Allows the mounting Aimpoint T1, T2, H1, T2 or clones to the Gen @ Sub 2000 Carbine.

Patent pending pivot design allows the gun to be folded as designed for compact storage.

Constructed from 6061 aluminum hard coat anodized for a lifetime of service.

Includes all mounting hardware

Weights

100 percent Made in the U.S.A.

Lifetime MI warranty

## **Installation Instructions:**

Have this part installed by a qualified gunsmith. Failure to follow these instructions will void the factory warranty.

- 1.) Make sure your firearm is unloaded and pointed in a safe direction.
- 2.) Set the mount on fourth slot to the muzzle end of the rifle. It can be mounted on the right or left hand side that is the shooter preference.
- 3.) With the provided wrench, slightly loosen and then start tightening the M-Lok nuts. Lightly snug.
- 4.) With the mount lightly snugged pull the mount down and push it toward the muzzle end to seat it in the M-Lok slot.
- 5.) Tighten the M-Lok screws to 40inch lbs.
- 6.) Swing the mount 180 degrees so you can mount the optic. The optic will be mounted with the objective end facing towards the stock with the mount swung to the side.
- 7.) Mount the red dot to the base with the provided screws. Torque the screws to the optic manufacturers torque specs. MI is not responsible if you strip the screws.
- 8.) Pull the charging handle to the rear and lock it.
- 9.) Use the length of provided para cord and tie a loop with the cord going through the hole in the stock that just slides over the charging handle. Ease the charging handle out of the notch and let it go forward. This will stretch the para cord. Make the loop smaller if needed. Do not let the handle slam onto the cord. Always ease the handle forward into the loop. This will keep the charging knob from hitting your optic with the gun folded. This is an important step – make sure the loop is as small as possible.
- 10.) To fold the rifle swing the mount to the side. Pull the charging knob to the rear and lock it. Pull the cord loop over the charging knob. Swing the mount back to the normal position.
- 11.) Never try to remove the pivot bolt, this is permanently installed. Doing so may break the bolt and will not be covered under warranty.

**Thank you for your purchase.**